

Mounting Instruction

Plug F3415 + Cable 130660

- 1** Remove the cable sheath
- 2** Push back the braided shield and strip the isolation from the center conductor
- 3** Put on the cable the rear part, the collet and the clamping sleeve
- 4** Put on the plastic sleeve with center contact and solder the contact
- 5** Push the plug case, the plastic sleeve and the other parts together
- 6** It must be ensured that the shield is clamped flat between the ground sleeve and the collet!

Cut overhanging braided shield and screw the plug components together